



# NEBULA SERIES

ALL-IN-ONE ARGB LIQUID CPU COOLER




## INSTALLATION GUIDE


### Part List




### Intel / AMD




### Intel / AMD




### Intel / AMD




### Intel 17XX




### Intel 115X / 1200



### AMD



### Wiring



**darkFlash DND series water-cooled LCD control software description**  
 1. The 9-pin USB port of the motherboard provides the power supply and data communication transmission of the LCD screen. Please make sure the wiring is complete before installing the software.  
 2. The software can be downloaded from the official website: <https://darkflash.com/maunal?classid=0000049/software> double-click STEUPEXE to install.  
 3. Desktop double-click the darkflash DN-D Setup icon to run the software  
 4. The real-time data monitoring/data transmission/opening and close the LCD screen and other functions are controlled by the software. After installation, the software will start with the computer boot up by default and stay in the background of the taskbar, please do not close it to force it to quit.



Fly to unlimited!

darkFlash

DARKFLASH INFOTECH Co., Ltd.  
www.darkflash.com